



SECURITY KAMERA

Anleitung

Vielen Dank für den Kauf und die Verwendung unseres Produkts. Bitte lesen Sie diese Kurzanleitung vor dem Gebrauch durch und bewahren Sie sie zum späteren Nachschlagen auf.

1. LIEFERUMFANG



Kamera



USB Kabel




Magnet-Halterung



Klebehalterung





Schrauben




Anleitung

2. ÜBERSICHT



1. LED Lampe
2. Mikrofon
3. 4MP Kamera
4. Lichtsensor
5. LED Anzeige
6. PIR Bewegungssensor
7. Knopf zum Öffnen des Gehäuses (beidseitig)
8. Gewinde für Halterung
9. Magnet-Halterung
10. Lautsprecher
11. Ein/Aus & Micro USB Buchse



3. BATTERIE AUFLADEN

Bitte laden Sie die Akkus vor dem erstmaligen Gebrauch mit einem USB-Kabel (am 5V-Adapter, nicht im Lieferumfang enthalten) vor der Installation für 8-10 Stunden vollständig auf.

HINWEIS: Die Lade-LED leuchtet während des Ladevorgangs durchgehend rot. Nach vollständigem Laden wechselt die Farbe der LED auf blau.



4. DOWNLOAD APP

Laden Sie die 'Vicohome'-App von Google Play™ oder dem App Store™ herunter. Die App ist auch verfügbar, indem Sie den QR-Code unten mit Ihrem Smartphone scannen.

HINWEIS:

Google Play™ ist eine Marke von Google Inc.

App Store™ ist eine Marke von Apple Inc.




5. WLAN EINRICHTUNG

Bevor Sie mit der WLAN-Konfiguration beginnen, beachten Sie bitte Folgendes:

- 1). Die Kamera funktioniert mit 2,4-GHz WLAN, aber nicht mit 5-GHz WLAN.
- 2). Vermeiden Sie die Verwendung von Sonderzeichen oder Symbolen wie (@~!#\$%^&*..., in Ihrem WLAN-Namen oder Passwort.
- 3). Führen Sie die Konfiguration in der Nähe Ihres WLAN-Routers durch.

Starten Sie die " Vicohome" APP und registrieren Sie ein Konto mit Ihrer Telefonnummer oder E-Mail-ID. Folgen Sie den weiteren Anweisungen in der App oder orientieren Sie sich an den folgenden Schritten.

Einrichtungsschritte:




1."Add Camera" drücken



2.Kamera einschalten



3.WLAN auswählen




4.Bestätigungston




5.QR Code scannen




6.Verbindungsaufbau




7.Verbindung...



8.Verbindung erfolgreich



9.Namen wählen



10.Fertig

6. ERSTER TEST

Tippen Sie nach der Einrichtung auf das Live-Ansichtsfenster in der App, um einen Test durchzuführen. Gehen Sie dann mit Ihrer Kamera zum gewünschten Installationsort. Stellen Sie sicher, dass an dem Installationsort ein starkes 2,4 GHz WLAN-Signal vorhanden ist. Möglicherweise müssen Sie einen WLAN-Repeater installieren oder die Kamera näher an Ihrem Router anbringen.

7. LIVE ANSICHT



1 Kamera wechseln	6 Wiedergabe
2 Stummschaltung	7 Einstellungen
3 Fensteranordnung	8 Webseite
4 Kamera hinzufügen	9 Fotogalerie
5 Batterie-Status	10 Benutzer Info
11 Teilen	12 Ton ein/aus
13 Alarm abspielen	14 Licht ein/aus
15 Sprechen	




1 Livebild beenden	5 WLAN Stärke
2 Video aufnehmen	6 SD/HD Qualität
3 Screenshot	7 Einstellungen
4 Ton ein/aus	8 Sprechen

Hinweis: die Live Ansicht nimmt nicht automatisch auf

8. VIDEO WIEDERGABE


Wenn die Micro-SD-Karte richtig installiert ist, können Sie die Videoclips wiedergeben, die nach der Bewegungserkennung automatisch aufgenommen wurden. Ein kostenloser 7-Tage-Cloud-Speicherdienst steht für Ihre Kamera bereit. Ein Upgrade können Sie unter Einstellungen buchen.



Drücken zum
Aktualisieren Ihres
Cloud Aufzeichnungs-
Servicepakets.


9. KAMERA FÜR ANDERE BENUTZER FREISCHALTEN

Folgen Sie diesen Schritten: Vicohome App öffnen >> Home >>  >> Einladen >> My QR Code >> Nun muss der weitere Benutzer den QR Code scannen.




10. ALARM EINSTELLUNGEN


Wenn eine Bewegung von Ihrer Kamera erkannt wird, erhalten Sie eine Alarmbenachrichtigung von der App. Sie können auch einstellen, dass das Blitzlicht und/oder der Alarm automatisch nach einer Bewegungserkennung aktiviert wird. Alternativ können Sie beides auch manuell in der App auslösen.




11. INSTALLATION



Schrauben Sie die Magnethalterung mit den beiliegenden Schrauben in eine Wand.



Alternativ können Sie auch das beiliegende doppelseitige Klebeband verwenden.



Befestigen Sie die Kamera mit der Magnethalterung und stellen Sie den Blickwinkel ein. Die Kamera muss sich in WLAN Reichweite befinden.

HINWEIS:

- ! Die Vicohome App erinnert Sie daran, Ihre Kamera zu laden, wenn der Akku schwach wird. Bitte laden Sie die Kamera mit dem mitgelieferten Micro-USB-Kabel und einem DC 5V 1,5A Handy-Ladegerät. Es dauert etwa 8-10 Stunden, um die Kamera vollständig aufzuladen.

- ! Wenn Sie Ihre Kamera über die Vicohome App verbinden, wird eventuell auf eine neue Firmware hingewiesen. Sie können das Firmware-Upgrade auch manuell in den Einstellungen der App überprüfen.
- ! Unterbrechen Sie die Stromversorgung nicht, wenn Sie die Firmware aktualisieren.

12. TECHNISCHE DATEN

Video & Audio	
Image Sensor	1/3" CMOS (4.0MP)
Resolution	Hi 3518E V300
Image Sensor	2560 x 1440
Stream	HD/SD dual stream
Infrared LED	High power IR LED with ICR
Lense	2.8mm/F2.0
Angle of view	110°
Miu.illumina.	Color:0.01 Lux;B&W:0.01LUX
Audio	2-way audio with noise cancellation
Storage	
Storage Type	Micro SD Card(Max 128G)
Cloud storage	Support
Recording	Triggered by PIR motion sensor

Network	
Wi-Fi Frequency	2.4 GHz ~ 2.4835 GHz
Standards	IEEE 802.11 b/g/n
Max. TX power	100 mW
Software	
App Name	VicoHome
System	iOS, Android
Remote View	Within 2 ~ 4 sec
Notification	Push notification within 2 ~ 4 sec
General	
Standby Current	300μA
Working Current(day)	250mA
Working Current(Night)	510mA
Battery life(full charge)	2~3 Months

General	
Battery Charging	DC5V 1A~2A (Micro USB Port)
Firmware Upgrade	OTA(Over-the-Air)
Dimension(mm)	72.1mm × 63.3mm × 97.4mm
Weight (KG)	0.35 KG
Working Temp. & Humidity	-20 C ~50 C ; <90%(No condensation)
Power Source	Lithium 21700 Battery (3.7V, 4800mAh) × 2
Bracket Data	
Weight (KG)	0.08 KG
Dimension (mm)	86mm × 56mm × 28mm

FAQ

F1: Wie gebe ich die Kamera für weitere Benutzer frei?

A1: Bitte schauen Sie in Kapitel 7 der Anleitung nach.

F2: Warum wird der Name des WLAN Netzwerks nicht angezeigt?

A2: Auf Apple-Geräten mit iOS13 und höher müssen Sie die "Standortberechtigung" für die App einschalten in den Systemeinstellungen aktivieren und auf "Bei Verwendung zulassen" ändern.

F3: Sieht man das Infrarot-Licht, wenn die Nachtsicht aktiviert ist?

A3: Durch die eingebauten Infrarot-Lampen zeigt die Kamera bei aktivierter Nachtsicht nur ein schwaches rotes Licht. Die Bildqualität ist jedoch auch bei schwachem Licht sehr klar.

F4: Was für WLAN Anforderungen gibt es?

A4: Bitte verwenden Sie ein 2,4-GHz-WLAN-Netzwerk. Das Gerät unterstützt keine 5-GHz WLAN-Netzwerke. Bitte stellen Sie die WLAN-Authentifizierungsmethode auf wpa2-psk oder eine andere niedrigere Sicherheitsstufe ein. Ein Passwort ist erforderlich.

F5: Wie weit sollte die Kamera vom Router entfernt platziert werden?

A5: Die Reichweite kann bis zu 150 Meter im freien Gelände erreichen. Die tatsächliche Reichweite hängt jedoch von der Stärke des WLAN Signals und der Umgebung ab.

F6: Wie lang ist die maximale Aufnahmezeit?

A6: Sie können die Aufnahmezeit in der App wählen. Die max. Länge eines Videos beträgt 3 Minuten.

F7: Wie kann man Videos schnell nach Kategorie anzeigen?

7A: Klicken Sie auf das Symbol in der oberen linken Ecke der Seite "Bibliothek", um die Suchfilter zu starten. Wählen Sie die Sucheinstellungen aus und klicken Sie dann auf "Speichern", um die Videowiedergabe anzuzeigen.

F8: Was soll ich tun, wenn das Gerät eine Störung aufweist?

A8: Drücken Sie lange auf den Einschaltknopf, um die Kamera neu zu starten. Wenn es keine Reaktion gibt, öffnen Sie die Rückseite der Kamera und drücken die Reset-Taste an der Seite unter der Abdeckung. Danach drücken Sie den Einschaltknopf erneut lange zum Neustart der Kamera.



ALBRECHT[®]

SECURITY | CAM

100% Wire-free & With Ai-powered Event Detection

Quick Start Guide

Thanks for purchasing and using our product. Please read this quick start guide before using, and keep it for future reference. Manual contents are subject to change without notice in accordance with our policy of continuous product improvement.

1. WHAT'S IN THE BOX



Battery Camera



USB Cable




Mount Bracket



Adhesive Tape





Screw Set




User Guide

2. CAMERA DIAGRAM



1. LED Light
2. Microphone
3. 4 MP Camera
4. Ambient Light Sensor
5. LED Indicator
6. PIR Motion Sensor
7. Back Shell Open Button
8. Threaded Bracket Interface
9. Strong Magnetic Chuck
10. Speaker
11. Power button & Micro USB Port




3. BATTERY CHARGING

Please fully charge the batteries with a USB Cable (5V adapter not included) for 8-10 hours before installation.

NOTE:

The charging LED will shine solid red when charging, and will turn to solid blue when it is fully charged.



4. DOWNLOAD THE APP

Download and install the 'Vicohome' app from Google Play™ or the App Store™. The App is also available by scanning the QR codes on the right, using your QR code scanner in your smart phone.

NOTE:

Google Play™ is a trademark of Google Inc.

App Store™ is a service mark of Apple Inc.




5. WI-FI SET UP

Before you start the Wi-Fi configuration, please note below:

- 1). The Battery camera works with 2.4 GHz Wi-Fi, but not with 5 GHz Wi-Fi.
- 2). Avoid using special characters or symbols like (@~!#\$%^&*..., in your Wi- Fi name or password.
- 3). Perform the configuration near your Wi-Fi router.

Launch the "Vicohome" APP and register an account with your mobile phone number or email. Start the Wi-Fi configuration, following the in-App instructions or referring to the following guiding steps.

Guiding STEPS:




1.Tap "+" to add device



2.Connection prompt



3.Input Wi-Fi password




4.Voice prompt




5.Scan QR code




6.Waiting for connection




7.Connecting



8.connection succeeds



9.Location name



10.Adding device complete


6. RUN A TEST

After setup, tap on the live view window in the app for a test. Then take the security camera outside to the installation spot and run a test there. Make sure the installation location is covered by strong 2.4 GHz Wi-Fi signal. If the camera doesn't work well outside, you may need to move the router closer to the installation location or invest in a Wi-Fi repeater.

7. LIVE VIEW INTERFACE



1 Change camera	6 Playback
2 Mute notification	7 Settings
3 Window layout	8 Home page
4 Add new devices	9 Photo gallery
5 Battery status	10 User Info
11 Sharing	12 Sound on/off
13 Play Alarm Sound	14 Light on/off
15 Speak	




1 Quit Live View	5 WiFi signal strength
2 Record video	6 SD/HD quality
3 Screenshot	7 Settings
4 Audio on/off	8 Speak

NOTE: Live viewing will not trigger device recording.

8. PLAYBACK


If the Micro-SD card is properly installed, you can playback the video clips taken after motion detection. A 7-days-rolling free cloud storage service is ready for your camera. You can also upgrade your cloud service pack in the settings.



Tap to upgrade your cloud recording service pack and enable Smart Ai Motion Detection area customization.


9. SHARE YOUR DEVICE

Steps: Run Vicohome App >> Home >>  >> Invite >> My QR Code >> Let the other user scan your QR Code.




10. ALARM SETTING

When a motion is detected by your camera, you will receive alarm notification from the App. You can also enable flashlight alarm and siren alarm to be triggered after motion events. The flashlight alarm and siren alarm can also be triggered manually in the camera settings.




11. INSTALLATION



Tighten the screw to the anchors, or directly to the wall until the bracket is fixed to the wall.



You can also use the double-sided tape instead of screws to fix the wall mount on a flat surface



Attach the camera to the bracket and adjust the angle to cover the surveillance area. Do make sure the camera is within the Wi-Fi range.

NOTE:

 Vicohome App will remind you to charge your camera when the battery is low. Please charge the camera with the provided Micro USB cable and a DC 5V 1.5A phone charger. During charging, the camera's LED indicator is in solid yellow, and when the camera is fully charged, the indicator will turn into solid green. It takes about 8-10 hours to fully charge your camera.

- ! When you connect your camera through the Vicohome App, it will notify you if a new firmware is available. You can also manually check the firmware upgrade in the settings of the App.
- ! Please make sure your camera is fully charged or connected to a power source to upgrade the firmware. Do not cut off the power when upgrading the firmware.

12. TECHNICAL PARAMETERS

Video & Audio	
Image Sensor	1/3" CMOS (4.0MP)
Resolution	Hi 3518E V300
Image Sensor	2560 x 1440
Stream	HD/SD dual stream
Infrared LED	High power IR LED with ICR
Lense	2.8mm/F2.0
Angle of view	110°
Miu.illumin.	Color:0.01 Lux;B&W:0.01LUX
Audio	2-way audio with noise cancellation
Storage	
Storage Type	Micro SD Card(Max 128G)
Cloud storage	Support
Recording	Triggered by PIR motion sensor

Network	
Wi-Fi Frequency	2.4 GHz ~ 2.4835 GHz
Standards	IEEE 802.11 b/g/n
Max. TX power	100 mW
Software	
App Name	VicoHome
System	iOS, Android
Remote View	Within 2 ~ 4 sec
Notification	Push notification within 2 ~ 4 sec
General	
Standby Current	300μA
Working Current(day)	250mA
Working Current(Night)	510mA
Battery life(full charge)	2~3 Months

General	
Battery Charging	DC5V 1A~2A (Micro USB Port)
Firmware Upgrade	OTA(Over-the-Air)
Dimension(mm)	72.1mm × 63.3mm × 97.4mm
Weight (KG)	0.35 KG
Working Temp. & Humidity	-20 C ~50 C ; <90%(No condensation)
Power Source	Lithium 21700 Battery (3.7V, 4800mAh) × 2
Bracket Data	
Weight (KG)	0.08 KG
Dimension (mm)	86mm × 56mm × 28mm

FAQ

Q1: How to invite family and friends to use my camera together?

A1: Please refer to the guiding steps on page 7 of this user guide.

Q2: Why doesn't the Wi-Fi name appear when I connect to Wi-Fi?

A2: On Apple devices with iOS13 and above, you need to turn on the "location permission" for the app in the system settings and change it to "allow when using."

Q3: Will the camera show red lights when night vision is activated?

A3: The built-in infrared lamp beads make the camera only show some dim red lights when night vision is activated, but the image quality is still clear under no light environment.

Q4: What are the requirements for Wi-Fi?

A4: Please use a 2.4GHz wireless network. The device does not support the 5GHz wireless network. Meanwhile, please set the Wi-Fi authentication method to wpa2-psk or other lower level of security method. A password is required.

Q5: How far should the camera be placed from the router?

A5: After testing, the Wi-Fi connection distance can normally reach up to 150 meters in the open area. However, the actual situation depends on the strength of Wi-Fi and its surrounding environment

Q6: What is the maximum length of recording time?

A6: You can choose the recording time in the app. The camera can record for a fixed time or "auto" mode, which depending on whether there is a person. The maximum length of a video is 3 minutes.

Q7: How to quickly view videos by category?

7A: Click the icon in the upper left corner of the "Library" page to start the search filters. Select the search settings and then click save to view the video playback.

Q8: What should I do when the device is in malfunction?

A8: Long press the power button to restart the camera. If there is no response, you can open the back shell of the camera, and then open the rubber plug on the side then press the reset button with a pointed object to force the power off, then long press the power button to restart the camera.